

APPENDIX A

X10 THERMOSTAT DECODE TABLE

DECODE TABLE B
Version 1.5

UNIT CODE	ON Command	OFF Command
	°F / °C	°F / °C
1	72° / 17°	SYSTEM OFF
2	73° / 18°	HEAT MODE
3	74° / 19°	COOL MODE
4	75° / 20°	AUTO MODE
5	76° / 21°	40° / 5°
6	77° / 22°	60° / 6°
7	78° / 23°	62° / 7°
8	79° / 24°	63° / 8°
9	80° / 25°	64° / 9°
10	81° / 26°	65° / 10°
11	82° / 27°	66° / 11°
12	83° / 28°	67° / 12°
13	84° / 29°	68° / 13°
14	86° / 30°	69° / 14°
15	88° / 31°	70° / 15°
16	90° / 32°	71° / 16°

Unit codes 1-16 set a specific temperature setpoint in the thermostat. °F or °C operation is set by dipswitch in the thermostat Control Unit.

This decode version also supports the Bright and Dim commands to increment (bright) or decrement (dim) the current setpoint by 1°. Holding down a Bright or Dim button on an X-10 controller will cause the setpoint to ramp up or down until released.